



## Using PowerLinked IPL Batteries with Your Device

### <Notice>

When using the IPL battery PowerLinked (*with an IPL or other IDX Endura digital battery*), the camera power may shut off unexpectedly before the active rearmost battery reaches the threshold to switch to the next IPL battery.

This symptom may be caused by the camera's "Shut Off Battery Voltage" set higher than 12.0 V.

Settings may vary depending on the camera model but should be set to 12.0 V or lower for the PowerLink function to activate properly.

**Please consult Product Support of your camera manufacturer for the recommended camera settings.**

*For more information, please contact IDX customer service at (310) 328-2850.*

- IDX System Technology, Inc.